



We bring good things to life.

FCC REGISTRATION INFORMATION

Your GE telephone equipment is registered with the Federal Communications Commission and is in compliance with parts 15 and 68, FCC Rules and Regulations.

1 Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the FCC Registration number and Righer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

Notes

- This equipment may not be used on coin service provided by the telephone company.
- Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment
 if you are on a party line. Check with your local telephone company.
- Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.

2 Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its communications facilities, equipment, operations of procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing to allow you to maintain uninterrupted service.

INTERFERENCE INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
- Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

HEARING AID COMPATIBILITY

This telephone system meets FCC standards for Hearing Aid Compatibility.

Introduction

Your GE 900 MHz Cordless Telephone is designed to give you flexibility in use and high quality performance. To get the most from your new cordless telephone, we suggest that you take a few minutes right now to read through this instruction manual.

IMPORTANT: This Should Not Be The Only Phone in Your Home

Because cordless phones operate on electricity, you should have at least one phone in your home that is not cordless, in case the power in your home goes out.

FCC REGISTRATION INFORMATION	
Interference Information	2
HEARING AID COMPATIBILITY	2
GETTING STARTED	
Before You Begin	
Modular Jack Requirements	
DESKTOP INSTALLATION	
WALL MOUNT INSTALLATION	
CORDLESS PHONE BASICS	
Making a Call	
In Use Indicator	
REDIAL (RE/PA)	
RECEIVING A CALL	
FLASH BUTTON	
VOL (VOLUME) SWITCH	٠ ٤
RING/PWR (RINGER AND POWER)	
Switch	٠ ٤
SELECTING A RING SOUND (PGM	_
Виттом)	
MUTE BUTTON	
TEMPORARY TONE	
Paging the Handset	
ADVANCED FEATURES	
CHANNEL BLITTON (CHAN)	1(

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

THE MEMORY FEATURE	10
STORING A NUMBER IN MEMORY	
CHANGING A STORED NUMBER	11
STORING A REDIAL NUMBER	
STORING A PAUSE IN MEMORY	11
DIALING A STORED NUMBER	12
CHAIN DIALING FROM MEMORY	
HEADSET AND BELT CLIP OPERATION	
CONNECTING HEADSET TO HANDSET	13
CONNECTING THE BELT CLIP	13
CHANGING THE BATTERY	14
BATTERY SAFETY PRECAUTIONS	14
TROUBLESHOOTING GUIDE	
GENERAL PRODUCT CARE	17
Causes of Poor Reception	
Service	
INDEX	
Accessory Form	20
LIMITED WARRANTY	21

THE PRODUCT.


RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER TRIANGLE IS A (OR BACK). NO USER-WARNING SIGN SERVICEABLE PARTS IN-ALERTING YOU OF SIDE. REFER SERVICING "D A NG ER O US TO QUALIFIED SERVICE VOLTAGE" INSIDE PERSONNEL.

POINT WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF I M P O R T A N T INSTRUCTIONS ACCOMPANYING THE PRODUCT.

SEE MARKING ON BOTTOM / BACK OF PRODUCT

GETTING STARTED

Make sure your package includes the items shown here.



BEFORE YOU BEGIN

MODULAR JACK REQUIREMENTS

You need an RJ11 type modular jack, which is the most common type of phone jack and might look like the one pictured here. If you don't have a modular jack, call your local phone company to find out how to get one installed.




FEATURE NOTE: Digital Security System

When you place the handset in the base, the unit verifies its security code which prevents false ringing from other cordless telephones. After a power outage or battery replacement, you should place the handset in the base for about 20 seconds to reset the code.

INSTALLATION NOTE: Some cordless telephones operate at frequencies that may cause interference to nearby TVs and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR. If interference continues, moving the cordless telephone farther away from the TV or VCR will often reduce or eliminate the interference.

DESKTOP INSTALLATION



- 1. Make sure base plate is securely fastened.
- 2. Plug the telephone line cord into the PHONE LINE jack on the base and into a modular jack.
- Plug the power supply cord into the POWER 9V DC jack on the base and into an AC outlet.
- 4. Set the T/P switch to T for touch-tone service, or P for pulse (rotary) service. If you don't know which type of service you have, check with the phone company.
- 5. Set RING switch (on the handset) to ON.
- 6. Raise the base antenna.
- 7. Place handset in the base to charge for 12 hours. The CHARGE/PAGE light (on the base) comes on to indicate that the battery is charging. If you don't charge the handset battery properly (for 12 hours) when you first set up the phone, performance of the battery will be compromised.

NOTE: Use only the Thomson power supply that is compatible with this unit. Using other adapters may damage the unit.

WALL MOUNT INSTALLATION

- Remove the handset hook; turn it upside down, and put it back in the slot. You need to do this so the handset doesn't fall out of the base.
- Plug the short telephone line cord into the jack marked PHONE LINE on the back of the unit and plug the other end into a modular wall jack.
- 3. Connect the power adapter to the POWER 9V DC jack on the phone.
- Install the base plate by putting the tabs into the slots on the top of the unit first, and then snapping the bottom tabs into place.
- Slip the mounting holes over the wall plate posts and slide the unit down firmly into place. (Wall plate not included.)
- Set the T/P switch to T for touch-tone service, or P for pulse (rotary) service. If you don't know which type of service you have, check with the phone company.
- 3 10 (0) 0=
- 7. Plug the other end of the power adapter into an AC outlet.
- 8. Set RING switch to ON.
- 9. Raise the base antenna.
- 10. Place handset in the base to charge for 12 hours. The CHARGE/PAGE light comes on to indicate that the battery is charging. You must charge the handset battery continuously (without using the phone) for 12 hours when you set up the phone.

CORDLESS PHONE BASICS

Making a Call

After initial set up, put handset in the base for 12 hours to charge the battery.

The only two things you need to know to make a call are:

- Press the TALK button before you dial.
- Press TALK or place the handset in the base to hang up.

IN USE INDICATOR


You know the phone is on when you see the IN USE indicator on the handset light.

REDIAL (RE/PA)

Press the TALK button, then press the RE/PA (redial/pause) button to redial the last number you called (up to 31 digits).

RECEIVING A CALL

To answer a call when the handset is out of the base, you must press the TALK button before you can talk.



FLASH BUTTON

Use the FLASH button to activate custom calling services such as call waiting or call transfer, which are available through your local phone company.

TIP: If you press the TALK button to activate custom calling services such as call waiting, you'll hang up the phone. Press FLASH instead.

VOL (VOLUME) SWITCH

Controls the volume of the handset's earpiece.

RING/PWR (RINGER AND POWER) SWITCH


This is a 3-position switch that controls the ringer and handset power.

When you move the switch to the left, the power is on and the ringer is on.

When you move the switch to the middle position, the power is on, but the ringer is off.

When you move the switch to the far right, the power is off and the ringer is off which saves battery power. You must turn PWR to ON (by sliding the switch to the middle or left position) in order to make calls or receive calls.

VOL (volume) switch (on the side of the handset)



SELECTING A RING SOUND (PGM BUTTON)

You can choose between two different ring sounds. To choose the first ring sound:

- 1. Press PGM.
- 2. Press 1.
- 3. Press PGM.

To choose the second ring sound:

- 1. Press PGM.
- 2. Press 2.
- 3. Press PGM.

To check your current ring sound selection, press PGM, press 3, and press PGM again.

MUTE BUTTON

Use the MUTE button to interrupt a phone conversation to talk privately with someone else in the room.

- 1. Press MUTE to activate mute feature (the BAT LOW light blinks).
- 2. Press MUTE again to turn it off.


TEMPORARY TONE

This feature enables pulse (rotary) service phone users to access touchtone services offered by banks, credit card companies, etc., by pressing the TONE button to temporarily make the phone touch-tone compatible. To get information about your bank account, for example, you would:

- 1. Press the TALK button.
- 2. Call the bank's information line.
- 3. Press the TONE button after your call is answered.
- 4. Follow the voice instructions to complete your transaction.
- 5. Hang up when finished. The phone returns to pulse (rotary) service.

PAGING THE HANDSET

Press the PAGE button on the base to locate a misplaced handset. When you press the PAGE button, the handset rings. Press the TALK button when you locate the handset. Remember that the ringer must be **ON** in order for the handset to ring.



ADVANCED FEATURES

CHANNEL BUTTON (CHAN)

If you ever experience any interference or don't have clear voice quality, press the CHAN button on the handset to advance to another channel.


THE MEMORY FEATURE

Store up to 10 numbers in memory for quick dialing.

STORING A NUMBER IN MEMORY

The phone must be OFF (PWR button ON, but no dial tone).

- 1. Press the MEM button
- 2. Dial the number (up to 24 digits).
- 3. Press MEM.
- 4. Press any number key (0-9) to store the phone number in that memory location.



CHANGING A STORED NUMBER

Use the same procedure to change a stored number as you do to store a number— you're just moving the phone number to a different memory location.

STORING A REDIAL NUMBER

The phone must be off (PWR button ON, but no dial tone).

- 1. Press MEM.
- 2. Press RE/PA (redial/pause).
- 3. Press MEM.
- 4. Press any number key (0-9) to store the phone number in that memory location.

STORING A PAUSE IN MEMORY

Use the RE/PA button to insert a pause when a delay is needed in the dialing sequence (for example, when you must dial a 9 to get an outside line or when you must enter codes to access your bank's information line). Each pause counts toward the 24 digit limit.

If you need to dial 9 to get an outside line and want to store a number in memory without having to dial 9 each time, you would:

- 1. Press MEM (phone must be off— PWR button ON, but no dial tone).
- 2. Press 9.
- 3. Press RE/PA (redial/pause).
- 4. Dial the phone number you want to store in memory.
- 5. Press MEM.
- 6. Press any number key (0-9) to store the phone number in that memory location.

TIP: If you need a longer pause, press RE/PA button more times.

DIALING A STORED NUMBER

- 1. Press the TALK button to get a dial tone.
- 2. Press MEM and then press the number for that memory location.

CHAIN DIALING FROM MEMORY

Use this feature to make calls which require a sequence of numbers, for instance if you use a calling card for a frequently called long distance number. Basically, you dial each part of the sequence from memory. The following example shows how you can use chain dialing to make a call through a long distance service:

The Number For	Memory Location
Long distance access number	7
Authorization code	8
Frequently called long distance number	9

- 1. Press the TALK button to get a dial tone.
- 2. Press the MEM button and then press 7.
- 3. When you hear the access tone, press MEM and then press 8.
- 4. At the next access tone, press MEM and then 9.


HEADSET AND BELT CLIP OPERATION

CONNECTING A HEADSET TO THE HANDSET

For hands free conversation, connect the headset (for 2-6921 only) to the HEADSET jack as shown. The handset receiver and microphone are disabled when the headset is connected.

Adjust the headset to rest comfortably on top of your head and over your ear. Move the microphone to approximately 2 to 3 inches from your mouth.


 Press the TALK button to answer or place a call before using the headset.



CONNECTING THE BELT CLIP

There are two slots, one on each side of the handset.


 Attach the belt clip (for 2-6921 only) by inserting the sides of the belt clip into the slots. Snap the ends of the belt clip into place.



CHANGING THE BATTERY

Make sure RING/POWER switch is **OFF** before you replace battery.

- Remove the battery compartment door.
- 2. Disconnect the cord attached to the battery pack and remove the battery pack from the handset.
- Insert the new battery pack and connect the cord into the jack inside the handset.
- 4. Put the battery compartment door back on.
- 5. Place handset in the base to charge. If you don't charge the handset battery properly (for 12 hours) when you first set up the phone and/or when you install a new battery pack, the battery's long-term performance will be compromised.



BATTERY SAFETY PRECAUTIONS

- Don't disassemble, mutilate, puncture, wet, or dispose of battery in fire.
 Like other batteries of this type, if it is burned or punctured, it could release toxic materials which can cause injury.
- Keep batteries out of the reach of children.



NOTE: The RBRC seal on the battery used in your Thomson Consumer Electronics product indicates that we are participating in a program to collect and recycle Nickel Cadmium batteries throughout the United States. Please call 1-800-8-BATTERY for information or contact your local recycling center.

TROUBLESHOOTING GUIDE

In case of difficulty, please check the following Troubleshooting Guide before seeking service.

Problem	Solution
No dial tone	 Check installation: — Is the base power cord connected to a working outlet? — Is TALK light on? — Is the telephone line cord connected to the base unit and the wall jack? Disconnect the base from the wall jack and connect another phone to the same jack. If there is no dial tone in the second phone, the problem might be your wiring or local service. Is the handset out of the base unit's range? Move closer to the base unit. Make sure the battery is properly charged (12 hours). Is the battery pack installed correctly? Make sure the RING/PWR switch on the handset is turned to ON. If the phone still does not work, disconnect the power cord and remove the battery pack. Place handset in the base for 10 seconds to allow it to reinitialize.
Dial tone is OK, but can't dial out	Make sure the T/P switch on the base is set correctly.
Handset does not ring	 Make sure the RING/PWR switch on the handset is turned to ON (the far left position). You may have too many extension phones on your line. Try unplugging some phones. See solutions for "No dial tone."
Cannot hear phone conversation	Set the volume control on side of handset to HI.
You experience static, noise, or fading in and out	 Change channels. Is handset out of range? Move closer to the base. Does the base need to be relocated? Charge handset battery. Make sure base is not plugged into an outlet with another household appliance.

Problem	Solution
Cannot hear the Page alert tone	 Set the RING/PWR switch on the handset to ON (the far left position).
Range is shorter than normal	Press the CHAN button during the conversation to select a new channel.
	Position the base antenna upward.
Battery will not hold a charge <i>or</i> is fully charged and the BAT LOW lights	 Be sure you are sufficiently charging the battery. When the battery has been charged for 12 hours, you can expect approximately 4 hours of talk time. Check to be sure battery contacts on both the handset and the base are making contact and are clean; free of dirt or lint. When the handset is placed in the base, check that the base CHARGE light is on.
BAT LOW light stays on	Place handset in base for 10 seconds to reset the phone. If that doesn't work, charge battery for 12 hours.
Memory Dialing doesn't work	 Did you program the memory location keys correctly? Did you follow proper dialing sequence? Make sure T/P switch is correctly set.
Unit locks up	 If the unit doesn't work, turn the power switch on the handset off. Hold down digit 2 and 8 simultaneously and then turn the power switch on. Put the handset back on the base and press the PAGE button until you hear a beep. If a power outage occurs while the handset is away from the base, the handset must be returned to the base when the power returns.
No link between base and handset.	ID code between handset and base could be lost. Follow these instructions: Make sure power switch on the handset is OFF. Turn the power switch ON while holding down digit 2 and 8 simultaneously. Put the handset down on the base. Press "PAGE" button until beep sound comes out. Beep sound indicates that ID code is correctly restored.

GENERAL PRODUCT CARE

To keep your telephone working and looking good, follow these guidelines:

- Avoid putting the phone near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Avoid dropping the handset, as well as other rough treatment to the phone.
- · Clean the phone with a soft cloth.
- Never use a strong cleaning agent or abrasive powder because this will damage the finish.
- Retain the original packaging in case you need to ship the phone at a later date.
- Periodically clean the charge contacts on the handset and base with a eraser.

Causes of Poor Reception

- · Aluminum siding.
- · Foil backing on insulation.
- Heating ducts and other metal construction can shield radio signals.
- You're too close to appliances such as microwaves, stoves, computers, etc.
- Atmospheric conditions, such as strong storms.
- Base is installed in the basement or lower floor of the house.
- Base is plugged into an AC outlet with other electronic devices.
- Baby monitor is using the same frequency.
- Handset battery is low.
- You are out of range of the base.

SERVICE

The FCC requires this product to be serviced only by the manufacturer or its authorized service agents. In accordance with FCC requirements, changes or modifications not expressly approved by Thomson Consumer Electronics could void the user's authority to operate this product. For instructions on how to obtain service, refer to the warranty included in this Guide.

Attach your sales receipt to the booklet for future reference or jot down the date this product was purchased or received as a gift. This information will be valuable if service should be required during the warranty period.

Purchase date	Name of store

INDEX

Α	0
Accessory Order Form 20	Order Form 20
В	P
Battery Installation 14 Battery Safety 14 Belt Clip 13 Buttons CHANNEL 10 FLASH 8	PAGE/FIND button 10 Paging the Handset 9 PHONE ON/OFF 7 Poor Reception 17 Product Care 17 PWR/RING (power and ringer) Switch 8
MEMORY 9, 10, 11, 12 PAGE/FIND 10 PHONE ON/OFF 7 REDIAL 7 TONE 9	R Receiving a Call 7 REDIAL 7 Ringer switch 10 Ringer switch (PWR/RING) 8
Chain Dialing 12 CHANNEL Button 10 CHARGE/IN USE light 5, 7 Cleaning the Phone 17 Connecting a Headset to the Handset 13 Connecting the Belt Clip 13	Service 18 Storing a Number in Memory 10 Storing a Redial Number 11 Storing a Tone Number with Pulse Dialing in Memory 11
F	Т
FLASH button 8	Temporary Tone 9
н	TONE button 9 Troubleshooting Guide 15
Headset 13	V
Installation 5	V VOL switch 8
	W
M Making a Call 7 MEMORY button 9, 10, 11, 12 Memory Feature 10 Memory Location 10	Wall mount installation 6

ACCESSORY ORDER FORM

DESCRIPTION	CATALOG NUMBER	PRICE*	QUANTITY	TOTAL
AC power supply adapter (white)	5-2420A or B	\$18.35		
AC power supply adapter (black)	5-4081	\$18.35		
Belt clip	5-2426	\$5.61		
Headset	5-2425	\$36.35		
Replacement battery	5-2358	\$21.35		
For credit card purchases	*Prices are subj	*Prices are subject to change without notice.	ice.	
Your complete charge card number, its expiration date and your	d your	Total Merchandise\$	\$	
signature are necessary to process all charge card orders.		We are required by law to collect the announciate cales tay for	ronriate cales tay for	
Copy your complete account number from your VISA card.		each individual state, county, and locality to which the merchandise is being sent.	to which the	
	Sales Tax	Sales Tax\$	\$	
My card expires:	Use VISA or MasterCa	Use VISA or MasterCard preferably, Money order or check must be in U.S. currency only, No COD or Cash.	y order or check must be	in U.S. currency
	All accessories are	All accessories are subject to availability. Where applicable, we will ship a	. Where applicable, we v	vill ship a
	Shipping, F	Shipping, Handling, and Insurance\$	rance \$	\$2.00
Copy your complete account number from your MasterCard		Total Amount Enclosed\$	49	
	Mail order for made payab	Mail order form and money order or check (in U.S. currency) made payable to Thomson Consumer Electronics, Inc. to:	ler or check (in U.S sumer Electronics,	s. currency) Inc. to:
Copy the number above your	Consumer Electronics	ctronics		

Please make sure that this form has been filled out completely.

— Apt._ ZIP

To:
Name____
Address_

Authorized Signature

State

This is your return label. Please print clearly.

P.O. Box 8419 Ronks, PA 17573-8419

Mail Order Department

name on the MasterCard

My card expires:

LIMITED WARRANTY

What your warranty covers:

· Any defect in materials or workmanship.

For how long after your purchase:

One year.

(The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.)

What we will do:

- Provide you with a new or, at our option, a refurbished unit.
- · The exchange unit is under warranty for the remainder of the original product's warranty period.

How to make a warranty claim:

- Properly pack your unit. Include any cables, etc., which were originally provided with the product. We
 recommend using the original carton and packing materials.
- Include in the package evidence of purchase date such as the bill of sale. Also print your name and address
 and a description of the defect. Send standard UPS or its equivalent to:

Thomson Consumer Electronics, Inc.

11721 B Alameda Ave.

Socorro, Texas 79927

- Pay any charges billed to you by the Exchange Center for service not covered by the warranty.
- · Insure your shipment in case of loss or damage. Thomson accepts no liability in case of damage or loss.
- A new or refurbished unit will be shipped to you prepaid freight.

What your warranty does not cover:

- Customer instruction. (Your Owner's Manual provides information regarding operating instructions and user controls. For additional information, ask your dealer.)
- Installation and set-up service adjustments.
- Batteries.
- Damage from misuse or neglect.
- Products which have been modified or incorporated into other products.
- Products purchased or serviced outside the USA.
- Acts of God, such as but not limited to lightning damage.

Product Registration:

Please complete and mail the Product Registration Card packed with your unit. It will make it easier to
contact you should it ever be necessary. The return of the card is not required for warranty coverage.

How state law relates to this warranty:

• This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

If you purchased your product outside the USA:

• This warranty does not apply. Contact your dealer for warranty information.